

MODEL MS2440


SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620



6/9/2005

SPOTNAILS MODEL MS2440

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70047	Exhaust Deflector
04	P-64377	O-Ring
05	P-24314	Cap Screw
06	P-32169	Flat Washer
07	P-60181	Cap
♦	08	P-62080 Gasket
	09	P-03076 Spacer
	10	P-15204 Exhaust Seal
	11	P-18442 Poppet Spring
♦	12	P-64399 Poppet O-Ring
	13	P-63043 Poppet
♦	14	P-64426 Poppet O-Ring
♦	15	P-64312 Cylinder Seal O-Ring
♦	16	P-64427 Piston O-Ring
	17	AS-06071 Piston & Driver Assembly
	18	P-06251 Driver Blade
	19	P-03082 Guide Spacer
♦	20	P-64428 Cylinder O-Ring
	21	P-05108 Cylinder
♦	22	P-64429 O-Ring
	23	P-15229 Bumper
♦	24	P-64430 O-Ring
	25	P-60190 Bottom Plate
	26	P-24453 Screw
	27	P-15202 Return Seal
	28	P-24358 Screw
	29	P-10304 Stationary Front Plate
	30	P-07357 Spring Pin
	31	P-10305 Removable Front Plate
	32	P-18333 Latch Spring
	33	P-08490 Wear Plate
	34	P-04062 Quick Clear Latch
	35	P-53165 Safety Guide

Ref No.	Part No.	Description
36	P-18328	Spring
37	AS-53065	Safety Assembly
38	P-07262	Pin
39	P-26143	Nut
40	P-01281	Body
41	P-64312	O-Ring
42	P-60156	End Cap
♦	43	P-64332 Valve Housing O-Ring
	44	P-22144 Trigger Valve Cap
♦	45	P-64333 O-Ring
♦	46	P-64334 O-Ring
♦	47	P-64335 O-Ring
	48	P-22145 Pilot Valve
♦	49	P-64336 O-Ring
	50	P-18227 Spring
♦	51	P-64383 Plunger O-Rings
	53	AS-22037 Plunger Assembly
♦	54	P-64328 O-Ring
	55	AS-21008 Trigger Assembly
	56	P-07327 Trigger Pin
♦	57	P-64240 O-Ring
	58	P-26126 Nut
	59	P-32170 Washer
	60	P-24430 Screw
	61	P-24432 Screw
	62	P-12417 Magazine Cover
	63	P-07337 Negator Spring Pin
	64	P-18334 Negator Spring
	65	P-13090 Bracket
	66	P-24383 Screw
	67	P-26159 Nut Plate
	68	P-09187 Pusher
	69	P-12415 Magazine
	70	P-07338 Pin
	71	P-97454 Filter (Optional)

♦ Parts Included In AS-97300 O-Ring And Seal Kit